



COLOUR & PROTECTION FOR THE INTERIOR



OIL STAIN

Colour code	Can size Litre	Article Number	Unit/ pack	Prices
3501 White	1.00	151 00 807	4	
	2.50	151 00 809	2	
3512 Silver Grey	1.00	151 00 812	4	
	2.50	151 00 814	2	
3514 Graphite	1.00	151 00 817	4	
	2.50	151 00 819	2	
3516 Jatoba	1.00	151 00 822	4	
	2.50	151 00 824	2	
3518 Light Grey	1.00	151 00 842	4	
	2.50	151 00 844	2	
3519 Natural	1.00	151 00 847	4	
	2.50	151 00 849	2	
3541 Havana	1.00	151 00 837	4	
	2.50	151 00 839	2	
3543 Cognac	1.00	151 00 827	4	
	2.50	151 00 829	2	
3564 Tobacco	1.00	151 00 832	4	
	2.50	151 00 834	2	
3590 Black	1.00	151 00 802	4	
	2.50	151 00 804	2	

MANUAL PROCESSING

Finished surface in 2 – 3 days, 2 – 3 coats

(1st/2nd Oil Stain, 2nd/3rd clear Polyx®-Oil)

Transparent colouring:

1. Apply very thinly to the clean and dry wood along the wood grain with Osmo Floor Brushes, Osmo Microfibre Roller or Osmo scraper.
2. Most brushstrokes can be removed within 30 minutes after applying.
3. Massage into the wood evenly with a white pad.
4. Drying time approx. 12 hours (normal climatic conditions, 23 °C/50 % rel. humidity). Lower temperatures and/or higher humidity can increase drying time. Allow for good ventilation

Intensive colouring:

5. Apply the first coat as described in points 1 – 4.
6. Apply the second coat, also very thinly, as described in point 1.
7. Massage into the wood evenly with a white pad.
8. Drying time approx. 12 hours, see point 4.
9. After step 4 or 8, carry out the final top coat with a clear Osmo Polyx®-Oil and allow to dry.

Note: Oil Stain can also be applied to smaller surfaces with a lint-free cloth.

RECOMMENDED USE

Osmo Oil Stain is recommended for all interior woods, especially for all wooden flooring, e.g. solid wood floors, parquet, blockstrip, OSB and cork as well as stairs and furniture surfaces.

ADVANTAGES

- > Attractive colour tones, transparent or intensive
- > Can be used with a scraper, roller or brush
- > Easy to apply
- > Based on natural oils

TOOLS



HARDENER FOR OIL STAIN



Colour code	Can size Litre	Article Number	Unit/ pack	Price
6631 Clear	0.06	151 00 528	6	

MANUAL PROCESSING

Finished surface in 1 day, 2 – 3 coats

1. Open the bottle of Hardener and pour contents into the Oil Stain can. Empty bottle completely. Stir thoroughly.
2. Processing to be carried out corresponds to that of Oil Stain.
3. Drying time approx. 4 – 5 hours (normal climatic conditions, 23 °C/ 50 % rel. humidity). Lower temperatures and/or higher humidity can increase drying time. Allow for good ventilation. (1st and 2nd coat.)
4. Final top coat is to be carried out with a clear Osmo Polyx®-Oil.

Note: Pot time is reduced down to 60 minutes by adding the Hardener. Please do not mix together more material than you can process with certainty within 45 minutes. If you do not use the entire can of Oil Stain, add 6 % Hardener – mix in a separate container!

RECOMMENDED USE

Osmo Hardener for Oil Stain acts as an additive for Osmo Oil Stain for accelerated drying.

ADVANTAGES

- > Shortened drying time
- > For high traffic areas
- > Ideal for public spaces

TOOLS

